

Revised May 2017 – For Software Version 3.0.10994

Satmap Active12 Settings		Recommended
Settings Profile	Internal Storage	Allows you to create individual profiles with different settings
Power Control	Automatic Screen Turn Off	Off after 3 Minute
	Alert When Screen Off	Off
	Automatic Power Saving	Always On
Advanced Power Control	Power Saving Mode	Normal
	Screen Backlight Boost	<i>Personal Choice</i> – We use 20 seconds (Time backlight stays on after a button press)
	Battery Type	Change to suit type of battery that you are using – SatMap LiPol Battery supply should be set to LiPol Rechargeable
Bluetooth	Sharing Data + Connecting to Bluetooth devices	Off – if not in use
Elevation	Elevation Data Source	Elevation from Map
	Altimeter calibration method	Auto
Backlight	Brightness + also used for night time or sunlight filter	70% - <i>Pressing the Backlight Boost button on your GPS Scrolls between 20%, 40%, 60%, 80% & 100% Backlight</i>
2 Box Layout	Data boxes that can be displayed on map page	<i>Personal Choice</i> - Route Name Location
4 Box Layout (upper)	Data boxes that can be displayed on map page	<i>Personal Choice</i> - GoTo Distance GoTo Time
4 Box Layout (lower)	Data boxes that can be displayed on map page	<i>Personal Choice</i> – ETA to End Nearest POI
GPS Settings	Position Display Format	OSGB (For use in the UK)
	Use GPS Compass	3kph / 1.8 mph / 1.62kn
Memory Status	Displays internal memory and SD card info	SD Card Information – We normally select the Icon with the Red Strike through line
Units and Set Speed	Units	<i>Personal</i> - Kilometres and Metres
	Target Speed	<i>Personal</i> - 5 kph (3.1mph)
	Pressure	mBar
Compass Settings	Compass Display	Degrees
	Grid Magnetic Angle	Automatic
	Bearing Display	Show Magnetic Bearings
Calibrate Compass	Follow on screen Instructions	Calibration available from Settings and Compass Page
Set Trip Data	Showing Inactive Routes	Hide Inactive Routes
	Auto Clear Trail Data	Off
	Auto Reset Log	Keep Log on New Route
Volume Control	Audio Playback Volume	<i>Personal</i> – We use 70%
	Beep Alert Count	<i>Personal</i> – We use Three beeps
Buttons Control	Key Click Sound	<i>Personal</i> – We use Off
	Map Button Activation	<i>Personal</i> – We use One Click (Hide)
	Button Handling	<i>Personal</i> – Left or Right Handed

Panning Speed	Speed of map panning and zooming speed	Very Fast
Cycling	Setting of wheel circumference size for when using additional cadence monitors etc	<i>Personal</i> – only required if using additional cadence monitors for Cycling
Screen Data Options	Auto Show POI information	Off
	Show Titles on Map	On (enables name of WP/POI to be viewed)
	Trail Marker Size	Large
Time Offset	Time Offset – For British Summer the time this offset does not automatically change	Adjust to - Plus 1 hour (UK) last Sunday of March Adjust to – No time offset (UK) last Sunday of October
Enter User Name	Default name Active 12 Can be changed	<i>Personal</i> – Can add your name and Telephone in case GPS is lost – Name also used for Bluetooth identification
Languages	Languages	English (optional)
About	Displays Software version and platform no. of your device	Satsync software can be used to update the software in your unit
	Test Unit	Used for Fault Finding with SatMap Technical Support



Telephone – 01669 621 044

Web Site – www.shepherdswalks.co.uk
E mail – info@shepherdswalks.co.uk

Web Site – www.gpstraining.co.uk
E mail – office@gpstraining.co.uk